

# Proper Installation of a Pin Stem

1. Taking into account the length of your pin stem, solder the joint and catch onto your pin back.
2. Insert the pin stem into the joint, making sure it is properly aligned (curving downward) with the joint as shown. Gently squeeze the joint ears to close them over the rivet.

